



SAFE JOB PROCEDURES

<u>JOB</u>	<u>Written by</u>	<u>Approved by</u>	<u>Date</u>
Band Saws	K. Thomas	K. Mardynalka	December 6, 2010

<u>Hazards</u>	<u>PPE Required</u>	<u>Additional Training</u>
Cuts, Amputation, electrical shock, noise, sawdust inhaled or in eyes, MSI	Eye Protection Hearing Protection Steel toes	On the job training
<p>Safe Work Procedure:</p> <ol style="list-style-type: none"> 1. Put on all the proper PPE before beginning the task 2. Ensure that saw is unplugged or locked out. Inspect the saw for defects 3. Inspect the work area to ensure it is clean 4. Assess the size and weight of the wood. If necessary obtain assistance. 5. Inspect the wood for defects and foreign objects. 6. Adjust the guard to 1/8th inch above the height of the wood being cut 7. Ensure that all safeguards are in place and start the saw. 8. Hold wood firmly and flat on the platform. Fed the wood into the blade with your body position to the side of the wood. Ensure that hands are kept within the safe zone identified on the platform 9. Shut off saw and wait for the blade to stop. 10. Remove wood from platform 11. De-energize and lock out the machine to clean it. 		



SAFE JOB PROCEDURES

Guidance Documents / Standards/ applicable legislation/ other:

Guidance documents: Operator's manual

WSH 214/2006: 2.1,6.1,8.0,12.3,12.4,16.4,16.5,