

Safe Work Procedures

Operating A Circular Saw (Corded or cordless)

Identified hazards: Cuts, noise, flying particles, electrocution

Required PPE: Safety footwear, eye & hearing protection,

1. Follow safe work practices at all times.
2. Ensure worker is properly trained.
3. Follow safety procedures as per the manufacturer's specifications.
4. Wear all required PPE.
5. Inspect equipment to ensure it is in good condition.
6. Ensure working area is free of debris.
7. Hold saw firmly to ensure the saw does not kick back.
8. Keep hands, fingers and feet clear of the blade.
9. Make sure the electrical cord is clear of the cutting area.
10. Make sure that materials being cut are manageable in length and size.
11. Unplug cord when saw is not in use.