

Safe Work Procedure/Guardrail Installation

Site:	Written By:	Approved By:	Date created:	Date of late revision
Morello Bay	Jared Driedger		March 29/08	

Hazards Present:	PPE	Additional Training Required
<ul style="list-style-type: none"> *Working out of Manlift Basket *Working at Heights *Handling of Material from inside building to outside (ie:Stand on plat form to install bracket onto facia board) 	<ul style="list-style-type: none"> *Gloves *Safety Vests *Safety Boots 	<ul style="list-style-type: none"> *Licensed Boomtruck operator *Knowledge of Boomtruck hand signals

Safe Work Procedures
<ul style="list-style-type: none"> *Hazard assessment prior to work to evaluate path for Boomtruck to ensure terrain is as level as conditions allow *Brackets to be installed on walkway platform at same time as facia board installation *Brackets to be taken down with use of elevated work plat form, Boomtruck, or basket truck, fall arrest systems will not be used in the installation of guardrails except from workers who will be strapped into work baskets. *Permanent roof anchors are to be installed at (1) point at mid-point in case of emergency, these are not to be used without further on site consultation. Documentation for anchor on site. They are to be installed on top of sheathing , under shingles. *Any ladder use will include a 4:1 ratio and will be tied off and supported at base.

Guidance Criteria	
<ul style="list-style-type: none"> *Workplace Heath & Safety Reg. Powered lift truck - 22.29 (1) - 22.29 (3) Design & construction -28.45, 28.46, 28.47 Ladders -13.7, 13.8, 13.11 *When truss tails are not longer than 2'/walkway platform is permitted to install facia board and will also be used to install brackets. *See attached bracket criteria 	<p>This "Safe Work Procedure" must be reviewed and updated as required</p>

All Procedures and relevant manuals, materials and equipment must be reviewed and approved.