

Safe Work Procedure

Acetylene

Facility:	Written By:	Approved By:	Date Created	Date of Last Revision:

Hazards Present:	PPE or Devices Required:	Additional Training Required:
Contents under pressure Inhalation Spills	Steel toed boots Face shield / safety glasses Safety glasses leather gloves Respirator	Eye wash station MSDS Manufacturer's recommendations First Aid

Safe Work Procedure:
<ol style="list-style-type: none"> 1 Use only in well ventilated areas 2 Do not wear contact lens when working with this chemical 3 Respirator selection must be based on the MSDS 4 Do not drag, roll or slide cylinders 5 Do use a suitable hand truck or cart to transport cylinder movement 6 Protect the cylinder from physical damage 7 Store in a cool, dry well ventilated area 8 Transport in a secure position, in a well ventilated vehicle

If an emergency situation occurs while conducting this task, or there is an equipment malfunction, engage the emergency stop and follow the lock out procedure

REPORT ANY HAZARDOUS SITUATIONS TO YOUR SUPERVISOR

Guidance Documents/Standards: MB Workplace Safety & Health Act & Regulations: 2.1 Safe Work Procedures 6 Personal Protective Equipment 35 W.H.M.I.S. 36 Chemical and Biological Substances	This Safe Work Procedure will be reviewed any time the task, equipment or materials change and at a minimum of every three years Reviewed By Worker Rep/ WSH Committee: Date:
--	---